

CR-3000/4000/6000 Series USB Interface Jumper Setting

Number	SW1-1	SW1-2	SW1-3	SW1-4
7(Default)	OFF	OFF	OFF	OFF : HID Class
6	ON	OFF	OFF	
5	OFF	ON	OFF	
4	ON	ON	OFF	
3	OFF	OFF	ON	ON : Vendor Class
2	ON	OFF	ON	
1	OFF	ON	ON	
0	ON	ON	ON	